



Making a Blackout on your new Windshield

#1- Pre-drill your holes!



#2- Mark how far up from the bottom you want the top of your Blackout to be with a sharpie pen.



#3- Follow the marker pen lines with masking tape and mask off the rest of the shield so there is no over spray.

You can use Home Depots exterior flat black spray paint for .99 cents per can. Give three coats letting each one dry.



#4- Let dry for a good 2 hours then you can mount the shield.



**#5- if you need to clean any over spray use only mineral spirits!
Anything else will eat your shield!**